




Ordering spares / Ersatzteil - Regelung / Pièces de rechange /  
 Parti di ricambio / Lista de recambios / Onderdelen bestellen  
 (NL/B) / Κωδικός Ανταλλακτικών / Bestilling af reservedele  
 / Beställning av reservdelar / Bestilling av reservedeler  
 / Резервни части / Запчасти / Części zapasowe / Piese  
 de schimb / Rendelhető alkatrészek / Запасні частини /  
 Резервни делови / Резервни делови / Atsarginių dalių  
 / Tellitavad varuosad / Rezerves daļas / Náhradní díly /  
 Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD, .....

Pos.	Part No.
1	A 960 500 NU
2	A 860 700 NU
3	A 963 298 NU
4	B 961 731 XX
5	A 860 899 NU
6	A 961 649 NU
7	A 860 898 XX
8	B 961 723 XX
9	B 960 473 XX
10	A 961 168 NU
11	A 961 462 NU
12	A 6678 XX



	<b>P</b>	<b>bar</b>				<b>Q</b> (3 bar)
	<b>T</b>	<b>°C</b>				<b>l/min</b>
						<b>29</b>





**CERAPLAN**



Ideal Standard


11.2021 / B565196











**B D252 ..**



Ideal Standard International NV  
 Corporate Village - Gent Building  
 Da Vincilaan 2  
 1935 Zaventem  
 Belgium

www.idealstandardinternational.com





0,3 MPa 3 bar	50°C	16°C	0	1	2	3	4	5	6	7	8	9
			°C	°C	°C	°C	°C	°C	°C	°C	°C	°C
	50°C	16°C	49,5	49,5	48	46	42,5	41	37	33,5	31	28
	65°C	16°C	65	65	63,5	60,5	57	53,5	49	44,5	39	34,5
	81°C	16°C	81	81	78,5	73	69	63,5	56	49	42,5	36